Size guide

HOW TO MEASURE

To find the right size, compare a similar garment at home with our measurements. Measure flat across the item - never around.

Chest width / Measure across the chest between the lowest point of the arm seams. Multiply with 2.

Waist width upper wear / Measure the width at the garment's narrowest point. Multiply with 2.

Waist width bottom wear / Place the garment on a flat surface with the front up and measure from side to side. Multiply with 2.

Bottom width / Measure from side to side at the bottom of the garment. Multiply with 2.

Center back length / Measure the center back from the neck seam to the end of the garment.

Sleeve length / Lay the arm flat and measure from the shoulder point to where the cuff ends.

Seat width / Place the garment on a flat surface with the front up and measure from side to side at the garment's widest point. Multiply with 2.

Thigh width / Measure straight across the width of the leg. Multiply with 2.

Inseam / Measure the inside leg from the crotch to the bottom of the trousers.


Foot width / Measure from side to side at the bottom of the trousers. Multiply with 2.

Length / Measure from the highest point of the garment to the end of the garment.

Collar length / Open the shirt and lay the collar flat. Measure from the center of the button to the outer edge of the buttonhole.

Ladies polo shirt Denise / Cotton & polyester

Art no: 5010050



	Normal size (cm)	xs	S	М	L	XL	2XL	3XL	4XL	5XL	6XL
Α	Chest width	82	88	94	100	106	114	123	132	141	150
В	Waist width	74	80	86	92	98	106	115	124	133	142
С	Bottom width	84	90	96	102	108	116	125	134	143	152
D	Center back length	60,5	62,5	64,5	66,5	68,5	70,5	72,5	74,5	76,5	78,5
Е	Sleeve length	14,5	15,5	16,5	17,5	18,5	19,5	20,5	21,5	22,5	23,5
F	Collar length	36	37,5	39	40,5	42	43,5	45	46,5	48	49,5