## Size guide

## HOW TO MEASURE

To find the right size, compare a similar garment at home with our measurements. Measure flat across the item - never around.

**Chest width /** Measure across the chest between the lowest point of the arm seams. Multiply with 2.

Waist width upper wear / Measure the width at the garment's narrowest point. Multiply with 2.

**Waist width bottom wear /** Place the garment on a flat surface with the front up and measure from side to side. Multiply with 2.

**Bottom width /** Measure from side to side at the bottom of the garment. Multiply with 2.

Center back length / Measure the center back from the neck seam to the end of the garment.

Sleeve length / Lay the arm flat and measure from the shoulder point to where the cuff ends.

**Seat width /** Place the garment on a flat surface with the front up and measure from side to side at the garment's widest point. Multiply with 2.

**Thigh width /** Measure straight across the width of the leg. Multiply with 2.

**Inseam /** Measure the inside leg from the crotch to the bottom of the trousers.


Foot width / Measure from side to side at the bottom of the trousers. Multiply with 2.

**Length /** Measure from the highest point of the garment to the end of the garment.

**Collar length /** Open the shirt and lay the collar flat. Measure from the center of the button to the outer edge of the buttonhole.

## Ladies cardigan Linda / Zipper / Merino wool & acrylic

Art no: 5011555



	Normal size (cm)	xs	s	М	L	XL	2XL	3XL	4XL	5XL
Α	Chest width	80	86	94	100	108	116	124	132	140
В	Waist width	72	80	88	96	104	112	120	128	136
С	Bottom width	70	76	84	90	100	112	120	128	136
D	Center back length	58	60	62	64	66	68	70	70	70
Е	Sleeve length	65	67	69	71	72,5	74	75,5	77	78,5