



Wrangler®

WORKWEAR

SIZE GUIDE



HOW TO MEASURE

To find the right size, compare a similar garment at home with our measurements. Measure flat across the item - never around.

Chest width / Measure across the chest between the lowest point of the arm seams. Multiply with 2.

Waist width upper wear / Measure the width at the garment's narrowest point. Multiply with 2.

Waist width bottom wear / Place the garment on a flat surface with the front up and measure from side to side. Multiply with 2.

Bottom width / Measure from side to side at the bottom of the garment. Multiply with 2.

Center back length / Measure the center back from the neck seam to the end of the garment.

Sleeve length / Lay the arm flat and measure from the shoulder point to where the cuff ends.

Seat width / Place the garment on a flat surface with the front up and measure from side to side at the garment's widest point. Multiply with 2.

Thigh width / Measure straight across the width of the leg. Multiply with 2.

Inseam / Measure the inside leg from the crotch to the bottom of the trousers.


Foot width / Measure from side to side at the bottom of the trousers. Multiply with 2.

Length / Measure from the highest point of the garment to the end of the garment.

Collar length / Open the shirt and lay the collar flat. Measure from the center of the button to the outer edge of the buttonhole.

Men's Stretch Service Trousers

Art no: 8600059



	Normal size (cm)	W28	W29	W30	W31	W32	W33	W34	W35	W36	W37	W38	W39	W40
A	Waist width	39	40,25	41,5	42,75	44	45,25	46,5	47,75	49	50,25	51,5	52,75	54
B	Seat width	50	51,25	52,5	53,75	55	56,25	57,5	58,75	60	61,25	62,5	63,75	65
C	Thigh width	29,3	30	30,6	31,3	31,9	32,6	33,2	33,9	34,5	35,2	35,8	36,5	37,1
D	Inseam 30	76	76	76	76	76	76	76	76	76	76	76	76	76
	Inseam 32	81	81	81	81	81	81	81	81	81	81	81	81	81
	Inseam 34	86	86	86	86	86	86	86	86	86	86	86	86	86
E	Bottom width	19,7	20	20,2	20,5	20,7	21	21,2	21,5	21,7	22	22,2	22,5	22,7